




ISO Node and GPS Hardware Updates

*P.S The newest version CR12/CR7 software **21.4.1.3** is including the Hardware updates for he (RS1, HDU and IDU)*


To check for ISO Node or GPS updates via Slingshot®:



1. Touch **Settings**  on the bottom left of the Home screen. The Settings menu will open.
2. Touch **Software Update**  on the Settings menu. The *Update* window will open.
3. Touch the **Hardware** tab.
4. If there is an update available via Slingshot® it will be listed on the *Hardware Update* window. **Listed are the RS1, HDU or IDU**

To learn more information about the current version, select the information icon. To see the if there is a newer version, compare the Current Version to the Latest Version.



5. To install the update, touch anywhere on the device cell except the information icon. A **Versions Available** drop-down will open below the list of Device Cells.
6. Touch the desired version from the **Versions Available** drop-down.



7. Touch **Start Update**. The update will install.
8. If desired, touch the **About**  tab to view information about the CRX including the software version, when the software version was installed, Run Hours, and Total Run Hours. If desired, touch **Erase Data** to reset the system and erase all data stored on the CRX. This includes all implements, Grower Farm Field data, and settings on the CRX.
9. Touch **Accept**  to save the displayed settings and return to the Settings menu.

P/N 016-0171-664 Rev. M Sep 2021 E37641

https://ravenindustries.mcoutput.com/fieldcomp/Content/SettingsMenu/Updates/ISO_GPS_Update.htm